





# IMPORTANT NOTICE - READ CAREFULLY Transducer Control Wire




### NOTES:

- DO NOT CONNECT BARE (SHIELD/GROUND) WIRE TO COM TERMINAL
- GROUND WIRE MUST BE FASTENED TO GROUND LUG
- CUT THE TRANSDUCER WIRE TO LENGTH
- DO NOT COIL EXCESS TRANSDUCER WIRE
- IF THE TRANSDUCER WIRE MUST CROSS POWER WIRES, DO SO AT 90°
- DO NOT ROUTE THE TRANSDUCER WIRE IN THE SAME CONDUIT OR ALONGSIDE POWER WIRES
- USE A NON-METALIC "T" FITTING TO PREVENT NOISE FROM COUPLING TO THE TRANSDUCER
- SOME TRANSDUCERS COME WITH A REDUCER TO LIMIT THE EFFECTS OF WATER HAMMER
- IF YOUR WATER SUPPLY HAS HIGH DEBRIS OR MINERAL CONTENT, IT IS RECOMMENDED THAT YOU REMOVE THE REDUCER FROM THE TRANSDUCER INLET USING A SMALL FLATHEAD SCREWDRIVER



# IMPORTANT NOTICE - READ CAREFULLY Transducer Control Wire




### NOTES:

- DO NOT CONNECT BARE (SHIELD/GROUND) WIRE TO COM TERMINAL
- GROUND WIRE MUST BE FASTENED TO GROUND LUG
- CUT THE TRANSDUCER WIRE TO LENGTH
- DO NOT COIL EXCESS TRANSDUCER WIRE
- IF THE TRANSDUCER WIRE MUST CROSS POWER WIRES, DO SO AT 90°
- DO NOT ROUTE THE TRANSDUCER WIRE IN THE SAME CONDUIT OR ALONGSIDE POWER WIRES
- USE A NON-METALIC "T" FITTING TO PREVENT NOISE FROM COUPLING TO THE TRANSDUCER
- SOME TRANSDUCERS COME WITH A REDUCER TO LIMIT THE EFFECTS OF WATER HAMMER
- IF YOUR WATER SUPPLY HAS HIGH DEBRIS OR MINERAL CONTENT, IT IS RECOMMENDED THAT YOU REMOVE THE REDUCER FROM THE TRANSDUCER INLET USING A SMALL FLATHEAD SCREWDRIVER



IMPORTANT NOTICE - READ CAREFULLY  
**Transducer Control Wire**



IMPORTANT NOTICE - READ CAREFULLY  
**Transducer Control Wire**

